

# 生醫暨醫療產品研發博士學程

DIP of the temperature measurement device prototype and an AOI system



指導老師:張創然老師  
博一甲 廖浩延 Hao-Yen Liao  
e-mail: howard31418@mail.mcut.edu.tw  
886-2-29089899 ext. 4580



# Outline



- **Introduction**
  - ✓ Infrared Thermography
  - ✓ AOI system
- **Materials and Methods**
- **Results**
  - ✓ Digital image process of Infrared Thermography
  - ✓ Find the holes from the image and make marks
- **Summary**



# Temperature measurement system


## Infrared Thermography

- Infrared thermography is the technique of converting infrared energy (radiant heat) into an image that a person can see and understand.
- The infrared energy emitted from an object is directly proportional to its temperature. Therefore temperatures are accurately measured by the infrared camera.




## Hardware components


The Arduino Nano is a small, complete, and breadboard-friendly board based on the ATmega328 (Arduino Nano 3.x). It has more or less the same functionality as the Arduino Duemilanove but in a different package.




Arduino Nano



Test Circuit



TFT LCD




AMG8833



## MATLAB

- MATLAB is a proprietary multi-paradigm programming language and numeric computing environment developed by MathWorks. MATLAB allows matrix manipulations, plotting of functions and data, implementation of algorithms, creation of user interfaces, and interfacing with programs written in other languages.



Code:

```
>> x=[27.00 27.25 29.00 26.00 28.25 28.25 25.25 24.75;27.00  
29.50 30.00 27.00 29.50 28.00 24.75 24.50;28.00 29.75 30.25  
30.25 30.50 27.50 24.50 25.50;30.25 30.25 30.50 30.25 30.50  
27.50 24.75 27.75;30.25 30.50 30.50 30.50 30.25 29.00 26.50  
30.25;30.25 30.50 30.25 30.50 30.75 30.25 30.00 29.75;30.00  
29.75 30.25 30.25 30.75 30.75 30.25 27.50;29.75 30.50 30.25  
30.50 30.25 30.25 29.25 26.75]  
>> V=imresize(x, 50,'bicubic');  
>> imshow(V)  
>> colormap(jet)  
>> caxis([20 40])  
>> colorbar
```


# Results

## Digital image process of Infrared Thermography

8X8 matrix data


27	27.25	29	26	28.25	28.25	25.25	24.75
27	29.5	30	27	29.5	28	24.75	24.5
28	29.75	30.25	30.25	30.5	27.5	24.5	25.5
30.25	30.25	30.5	30.25	30.5	27.5	24.75	27.75
30.25	30.5	30.5	30.5	30.25	29	26.5	30.25
30.25	30.5	30.25	30.5	30.75	30.25	30	29.75
30	29.75	30.25	30.25	30.75	30.75	30.25	27.5
29.75	30.5	30.25	30.5	30.25	30.25	29.25	26.75

MATLAB  
bicubic resize



400X400 pixel image


MATLAB



8X8 pixel image

```
[[165 172 193 134 186 186 113 97]  
[165 198 203 165 198 184 97 90]  
[184 200 205 205 207 179 90 120]  
[205 205 207 205 207 179 97 181]  
[205 207 207 207 205 193 151 205]  
[205 207 205 207 210 205 203 200]  
[203 200 205 205 210 210 205 179]  
[200 207 205 207 205 205 195 158]]
```

Python  
bicubic resize






400X400 pixel image




# AOI system-defect detection and measurement

Automated Optical Inspection




1. Detection resolution 50  $\mu\text{m}$ .
2. Detection efficiency 12pcs/min (60 holes).
3. Create AOI defect database.
4. Programming and testing of robotic arm, integration of machine software and hardware.
5. Customized equipment size.

# Unit definition-conveyor + CCD on both sides



Trigger CCD to take pictures & confirm workpiece.  
(Optical fiber, fiber for confirm the workpiece)

Conveyor



Robot



CCD



Light



Moving process:  
The conveyor moves the workpiece  
and takes pictures by CCD.



# Case Video



*Research Center for Intelligent Medical Devices*


# Results

## Find the holes from the image and make marks

### Modified labeling example


#### Hole coordinates

- $X1, Y1 =$   
1818.38 917.78
- $X2, Y2 =$   
655.21 1002.81



### Modified Hough Circle example

```
circles = cv2.HoughCircles(img,  
cv2.HOUGH_GRADIENT,1,500,param1=8,  
param2=10,minRadius=180,maxRadius=330)
```



# Summary

- MATLAB can process input data from 8x8 matrix to a figure.
- Bicubic algorithms let images more smoothly by fill in the vacancy of the matrix data.
- Modified labeling example to find the holes from the image and make marks.
- Modified Hough Circle example to find the holes from the image but the result is not so good so far.



THANK YOU !






```
# Opening the image and converting it to grayscale.
a = Image.open('/content/drive/MyDrive/DIP colab/temperature measurement_8_8.png').convert('L')
a = numpy.asarray(a)
a1 = Image.open('/content/drive/MyDrive/DIP colab/OUTPUT/temperature measurement_8_8output.png').convert('L')
a1 = numpy.asarray(a1)
print(a)
print(a1)

fig = plt.figure(figsize=(40, 40))
ax = fig.add_subplot(1, 2, 1)
imgplot = plt.imshow(a, cmap='jet')
ax.set_title('Before')
ax = fig.add_subplot(1, 2, 2)
imgplot = plt.imshow(a1, cmap='jet')
ax.set_title('After')

fig, ax = plt.subplots(ncols=1,nrows=1,
    figsize=(6, 6))
# plots the label image on the
# previous plot using colormap
ax.imshow(a1, cmap='jet',vmin=150, vmax=255)
plt.savefig('/content/drive/MyDrive/DIP colab/OUTPUT/temperature measurement_8_8output2.png')
```



```
# Function: bicubic
# Author: YuYao
# Time: 10/09/2019

import numpy as np
import matplotlib.pyplot as plt
import cv2

def base_function(x, a=-0.5):
    # describe the base function sin(x)/x
    Wx = 0
    if np.abs(x)<=1:
        Wx = (a+2)*(np.abs(x)**3) - (a+3)*x**2 + 1
    elif 1<=np.abs(x)<=2:
        Wx = a*(np.abs(x)**3) - 5*a*(np.abs(x)**2) + 8*a*np.abs(x) - 4*a
    return Wx

def padding(img):
    h, w, c = img.shape
    print(img.shape)
    pad_image = np.zeros((h+4, w+4, c))
    pad_image[2:h+2, 2:w+2] = img
    return pad_image

def draw_function():
    a = -0.5
    x = np.linspace(-3.0, 3.0, 100)
    y = np.zeros(len(x))
    for i in range(len(x)):
        y[i] = base_function(x[i], a)
    plt.figure("base_function")
    plt.plot(x, y)
    plt.show()

def bicubic(img, sacle, a=-0.5):
    print("Doing bicubic")
    h, w, color = img.shape
    img = padding(img)
    nh = h*sacle
    nw = w*sacle
    new_img = np.zeros((nh, nw, color))

    for c in range(color):
        for i in range(nw):
            for j in range(nh):
                px = i/sacle + 2
                py = j/sacle + 2
                px_int = int(px)
                py_int = int(py)
                u = px - px_int
                v = py - py_int

                A = np.matrix([[base_function(u+1, a)], [base_function(u, a)], [base_function(u-1, a)], [base_function(u-2, a)]])
                C = np.matrix([base_function(v+1, a), base_function(v, a), base_function(v-1, a), base_function(v-2, a)])
                B = np.matrix([[img[py_int-1, px_int-1][c], img[py_int-1, px_int][c], img[py_int-1, px_int+1][c], img[py_int-1, px_int+2][c]],
                                [img[py_int, px_int-1][c], img[py_int, px_int][c], img[py_int, px_int+1][c], img[py_int, px_int+2][c]],
                                [img[py_int+1, px_int-1][c], img[py_int+1, px_int][c], img[py_int+1, px_int+1][c], img[py_int+1, px_int+2][c]],
                                [img[py_int+2, px_int-1][c], img[py_int+2, px_int][c], img[py_int+2, px_int+1][c], img[py_int+2, px_int+2][c]]])

                new_img[j, i][c] = np.dot(np.dot(C, B), A)

    return new_img

if __name__ == '__main__':
    sacle = 50
    path = "/content/drive/MyDrive/DIP colab/temperature measurement_8_8.png"
    img = cv2.imread(path)
    new_img = bicubic(img, sacle)
    cv2.imwrite( "/content/drive/MyDrive/DIP colab/OUTPUT/temperature measurement_8_8output.png", new_img)
    print("Finish")
```



# Python Code

## Modified labeling example

```
# Opening the image and converting it to grayscale.
a = Image.open('/content/drive/MyDrive/DIP_colab/RCIM
D_SC_TEST1.jpg').convert('L')
# a is converted to an ndarray.
a = numpy.asarray(a)
# Threshold value is determined by
# using Otsu's method.
thresh = threshold_otsu(a)
print('thresh=',thresh)
# The pixels with intensity greater than
# "theshold" are kept.
b = a > 220

c1 = label(b)
# c is saved as label_output.png

# On the labelled image c, regionprops is performed
d1 = regionprops(c1)

fig = plt.figure(figsize=(40, 40))
ax = fig.add_subplot(1, 2, 1)
imgplot = plt.imshow(b, cmap='gray')
ax.set_title('Before')
ax = fig.add_subplot(1, 2, 2)
imgplot = plt.imshow(c1, cmap='YlOrRd')
ax.set_title('After')
```

```
for i in d1:
    # Printing the x and y values of the
    # centroid where centroid[1] is the x value
    # and centroid[0] is the y value.
    #print(i.centroid[1], i.centroid[0])
    # Plot a red circle at the centroid, ro stands
    # for red.
    plt.plot(i.centroid[1],i.centroid[0],'ro')
    # In the bounding box, (lr,lc) are the
    # co-ordinates of the lower left corner and
    # (ur,uc) are the co-ordinates
    # of the top right corner.
    lr, lc, ur, uc = i.bbox
    # The width and the height of the bounding box
    # is computed.
    rec_width = uc - lc
    rec_height = ur - lr

    # Rectangular boxes with
    # origin at (lr,lc) are drawn.
    rect = mpatches.Rectangle((lc, lr),rec_width,
                               rec_height,fill=False,edgecolor='black',
                               linewidth=2)
    # This adds the rectangular boxes to the plot.
    ax.add_patch(rect)
print('DW=',rec_width)
print('DH=',rec_height)
#plt.savefig('/content/drive/MyDrive/DIP_colab/OUTPUT/8888#.png')
plt.show()
```



## Modified Hough Circle example


```
import numpy as np
import scipy.ndimage
from PIL import Image
import cv2
import matplotlib.pyplot as plt

# opening the image and converting it to grayscale
a = Image.open('/content/drive/MyDrive/DIP_colab/RCIMD_SC_TEST1.jpg')
a = a.convert('L')
# Median filter is performed on the image to remove noise.
img = scipy.ndimage.filters.median_filter(a, size=10)
# Circles are determined using Hough circles transform.
circles = cv2.HoughCircles(img, cv2.HOUGH_GRADIENT, 1, 500, param1=8,
                           param2=10, minRadius=180, maxRadius=330)
```


```
# circles image is rounded to unsigned integer 16.
circles = np.uint16(np.around(circles))
# For each detected circle.
for i in circles[0,:]:
    # An outer circle is drawn for visualization.
    cv2.circle(img, (i[0], i[1]), i[2], (0, 255, 0), 2)
    # its center is marked
    cv2.circle(img, (i[0], i[1]), 2, (0, 0, 255), 3)
# Saving the image as houghcircles_output.png
fig = plt.figure(figsize=(80, 80))
ax = fig.add_subplot(1, 2, 1)
imgplot = plt.imshow(a, cmap='gray')
ax.set_title('Before')
ax = fig.add_subplot(1, 2, 2)
imgplot = plt.imshow(img, cmap='gray')
ax.set_title('After')
# plt.savefig('/content/drive/MyDrive/DIP_colab/OUTPUT/RCIMD_SC_TEST1_1_Hough Circle.png')
plt.show()
```








## Digital image process of Infrared Thermography



Data



27	27.25	29	26	28.25	28.25	25.25	24.75
27	29.5	30	27	29.5	28	24.75	24.5
28	29.75	30.25	30.25	30.5	27.5	24.5	25.5
30.25	30.25	30.5	30.25	30.5	27.5	24.75	27.75
30.25	30.5	30.5	30.5	30.25	29	26.5	30.25
30.25	30.5	30.25	30.5	30.75	30.25	30	29.75
30	29.75	30.25	30.25	30.75	30.75	30.25	27.5
29.75	30.5	30.25	30.5	30.25	30.25	29.25	26.75




image




```
[[165 172 193 134 186 186 113 97]
 [165 198 203 165 198 184 97 90]
 [184 200 205 205 207 179 90 120]
 [205 205 207 205 207 179 97 181]
 [205 207 207 207 205 193 151 205]
 [205 207 205 207 210 205 203 200]
 [203 200 205 205 210 210 205 179]
 [200 207 205 207 205 205 195 158]]
```

# End controller and robot inertia calculation



## Rated eccentricity setting





EPSON Robot LS3 Setup					EPSON Robot LS6 Setup				
項次	項目	參數	單位	備註	項次	項目	參數	單位	備註
1	重量	1.4	kg(K)		1	重量	1.6	kg(K)	
2	長度	172	mm		2	長度	172	mm	
3	慣性	0.01	kg-cm^2		3	慣性	0.01	kg-cm^2	
4	離心率	9.6	mm		4	離心率	9.6	mm	

## Inertia calculation



# Robot simulation



- Confirm moving range
- Avoid singularity points

